

SunSAI/P Release Notes



THE NETWORK IS THE COMPUTER™

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, CA 94303-4900 USA
650 960-1300 Fax 650 969-9131

Part No. 805-6948-10
November 1998, Revision A

Send comments about this document to: docfeedback@sun.com

Copyright 1998 Sun Microsystems, Inc., 901 San Antonio Road • Palo Alto, CA 94303 USA. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, AnswerBook, Java, the Java Coffee Cup, SunSolve, SunVTS, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 1998 Sun Microsystems, Inc., 901 San Antonio Road • Palo Alto, CA 94303 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, AnswerBook, Java, le logo Java Coffee Cup, SunSolve, SunVTS, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REPONDRE A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



SunSAI/P Release Notes

This document contains important information about the SunSAI/P adapter and software.

Note – For access to the Sun bug report database, and for information on how to get the latest patches and patch revisions, please visit the SunSolvesm website at <http://sunsolve.sun.com>.

Suggested Maximum Number of SunSAI/P Adapters Per System

The table below lists the suggested maximum number of SunSAI/P adapters per Sun™ system. These numbers are current at the time of the printing of this document.

TABLE 1 Suggested Maximum Number of SunSAI/P Adapters Per System

Sun System	Number of SunSAI/P Adapters
Ultra™ 5	3
Sun Enterprise 5S	3
Ultra 10	4
Sun Enterprise 10S	4
Ultra 30	4
Ultra 60	4

TABLE 1 Suggested Maximum Number of SunSAI/P Adapters Per System (*Continued*)

Sun System	Number of SunSAI/P Adapters
Sun Enterprise™ 250	4
Sun Enterprise 450	4
Sun Enterprise 3000/4000/5000/6000	4
Sun Enterprise 3500/4500/5500/6500	4

Note – The SunSAI/P software has been tested on the following Solaris operating environments: Solaris 2.5.1 Hardware: 4/97, 8/97, 11/97, Solaris 2.6, and Solaris 7.

Sun Port Manager

The Sun™ Port Manager (`spm`) utility is provided to display port settings and to run diagnostics on the SunSAI/P adapter. The correct way to exit from the `spm` utility is to press the `q` key. If you attempt to use the Escape key to quit the utility, the `spm` utility may terminate with an error and create a core file.

Also, the `spm` utility will display the port settings of no more than eight SunSAI/P adapters. Refer to Sun bug report number 4176486 for more information.

Dial In Modems May Not Hang Up

If you use modems for dial in purposes, you may experience a problem where a modem will not hang up the phone line connection after all of the processes running on the port exit. As a workaround, configure the modem to be a bi-directional modem.

Please refer to the Sun bug report number 4178202 for more information.

Using Hardware Flow Control

To use clear to send (CTS)/request to send (RTS) hardware flow control with devices such as modems, we recommend using the options provided by the /opt/SUNWconn/bin/sitty utility. Use the sitty rtspace and ctspace options instead of the following Solaris stty command options: crtsccts, crttsxoff, rtsxoff and/or ctsxon. Refer to the *sitty(1m)* man page and Chapter 7 of the *SunSAI/P User's Guide* for more information about the sitty utility.

SunVTS saiptest

At the time of the printing of this document, the SunVTS™ saiptest diagnostic may fail when testing a SunSAI/P adapter using the external 25 port loopback mode option. As a workaround, you may verify the SunSAI/P adapter using the saiptest internal loopback test mode. For more information, refer to Sun bug report number 4171288.

saipconfig Utility Changes



Caution – Only run the saipconfig utility on systems with at least one SunSAI/P adapter installed. Running the saipconfig utility on a system without a SunSAI/P adapter will cause the driver not to load if the adapter is installed later.

Configure Up to 16 SunSAI/P Adapters

The saipconfig utility, which is included with the SunSAI/P software, has changed since the printing of the *SunSAI/P User's Guide* (805-6947-10). The utility can now be used to configure up to 16 adapters. However, you should not install more adapters into your system than are suggested in TABLE 1.

Manual Configuration Procedure Changed

Note – Since the printing of the *SunSAI/P User's Guide*, the saipconfig procedure for manually configuring the driver software has changed. Please see the section below for the correct procedure.

Use the saipconfig utility to configure the SunSAI/P adapters on your system manually. The utility will ask you a series of questions about how you want to customize the adapters. After you have answered these questions, the utility will reconfigure the driver software.

- 1. Become superuser, or log onto to your system console as root.**

- 2. Start the saipconfig utility by typing:**

```
# /etc/opt/SUNWconn/bin/saipconfig
```

- 3. To configure the adapters manually, answer no (n) to this question:**

```
The installation has detected 1 SunSAI/P serial adapter.
```

```
Would you like to automatically install the default configuration? n
```

- 4. Decide whether you want to select your own instance number:**

```
Would you like to select your own instance numbers? (y/n)? y
```

In this example, we have answered **y**, so saipconfig will prompt us for instance numbers later in the procedure. If we answered **n**, then the utility would not prompt us for instance numbers.

The `saipconfig` utility will ask you questions about how you want to configure the SunSAI/P interfaces.

This script installs the Sun PCI Serial Asynchronous Interface driver :

This script also installs the information needed by Solaris to use the additional ports available through this driver. Depending upon your system, this driver may support up to 16 Host Adapters and (0-51) instances.

Press <CR> to proceed or "Q" to quit:

5. Press the Return key to configure your driver software.
6. Type the number of SunSAI/P adapters you want to configure on your system:

NOTE: Although (0-51) instances are allowed, this driver only supports 16 actual adapters at one time.
How many adapters do you wish to install (1-16)?

For each adapter that you specified in Step 6, you will be asked the questions shown in Step 7 through Step 9.

7. Decide if you want to enable interrupts on the SunSAI/P adapter.
- Type "y" to disable interrupts (the default value), or type "n" to enable interrupts, on the adapter.

Note – We recommend that you use the default setting of disabled interrupts.

Configuring adapter 0.

Adapter type is 8-port PCI Async Intelligent Adapter.

8-port adapter:

In order to reduce response time to small packets (latency), it may be helpful to enable interrupts on the adapter. However, doing this will significantly increase driver CPU usage on your Solaris system. By default, interrupts are disabled. To enable interrupts, answer no.

Do you want to keep interrupts disabled on the adapter? (y/n)? **y**

- 8. If you answered **y** to Step 4, you will be prompted for the instance number of the adapter:**

```
What instance number would you like for this adapter? 1
```

The saipconfig utility will then display the selected configuration of the adapter.

```
You have selected the following configuration for adapter 0:
```

```
Adapter Type: 8-port PCI Async Intelligent Adapter.
```

```
Module Port Names
```

```
-----
```

```
1      term/a000 - term/a007 -- also /dev/cua/axxx  
Interrupts disabled.
```

```
Is this configuration acceptable (y or n)? y
```

- 9. Type “Y” if you are satisfied with this adapter’s configuration.**

Type “n” if you are not satisfied with the configuration.

```
Is this configuration acceptable (y or n)? n
```

```
Hit <CR> to re-configure adapter #0:
```

Press the Return key to return to Step 7.

After answering these questions for all of the SunSAI/P adapters on your system, saipconfig will configure the interfaces automatically. When saipconfig has finished configuring the interfaces, you will see this message:

```
Configuration Completed.
```